

Check position of any cut-away on slide in relation to diaphragm. Then pull off old diaphragm and remove plastic rings with side cutters or carpet knife. Take care not to damage or scratch the slide.



Honda CB360 Carb Diaphragms Installation Guide

Plastic rings snap off when cut. This exposes a groove used for the thick rubber tire in the new diaphragm.





Make sure to install the diaphragm from the top side, the rubber is limited on how much it will stretch. New diaphragm has a thick rubber middle section that replaces the plastic rings. Use a drop of super glue to hold in place.

The new diaphragms do not have a reference notch the old ones did. The proper orientation of the slide is with the two air holes at the bottom of the slide face the choke butterfly towards the air cleaner. Use a light coat of gasket sealer on the top cap edges.

